# **EN Instruction leaflet**



RTM ABIx Freedrive RTM ABIx EasyTeach EN Flange



#### 1 Identification


This instruction leaflet describes how to assemble the flange to the cobot and the welding torch to the torch mount

- ► Consult the documentation for the welding components.
- ► Only qualified personnel are permitted to perform work on the device or system.

### 2 Product description


The RTM ABIx Freedrive/RTM ABIx EasyTeach flange is available in a one-button Freedrive version (Fig. 1) or a three-button EasyTeach version (Fig. 2) as shown below. Each has an 8-pin M8 socket interface.

Fig. 1 RTM ABIx Freedrive




The ZeroG button releases the robot axis (ZeroG) and makes it easier to move the robot by hand.

Fig. 2 RTM ABIx EasyTeach




#### 3 Mounting the flange and the welding torch

Fig. 3 Mounting the flange and the welding torch




- 1 Fix the RTM ABIx Freedrive/RTM ABIx EasyTeach flange with cylinder head screws (I) on the robot (A) (tightening torque max. 4 Nm).
- 2 Connect the connection cable (C) to the robot connection (B).
- 3 Insert the welding torch (G) in the torch mount (H) and fix manually.
- 4 Tighten the clamp (F) with cylinder head screws (E) (tightening torque max. 4 Nm).

## 4 Circuit diagram RTM ABIx Freedrive



## 5 Circuit diagram RTM ABIx EasyTeach







Alexander Binzel Schweisstechnik GmbH & Co. KG Kiesacker • 35418 Buseck • GERMANY T +49 64 08 / 59-0 F +49 64 08 / 59-191 info@binzel-abicor.com

www.binzel-abicor.com

